



Precision Thickness Measurement

CLAS-NX V1.0 Release Notice

December 8, 2017

V1.0:

- Initial release.

Dependencies:

1. Windows 10 64-bit
2. Microsoft .NET Full Framework V4.5 or later.
3. Microsoft Visual C++ 64-bit Runtime 2013.
4. Lumetrics Wavefront Backend Service
5. USB Camera Runtime (for CLAS-FX)
6. EPIX XCLib V3.8 64-bit. (for CLAS-XP)
7. EPIX Frame Grabber Drivers, 64-bit (for CLAS-XP)

Installation:

1. Remove any installed CLAS-NX software using Apps & Features.
2. Run the LumetricsInstaller and install all items listed.

Notes:

1. Data files have been changed to XML format and are not backwards compatible.

Known Issues:

- Cameras cannot be disconnected or power cycled during software operation.
- System hibernation is not supported.
- Loading files from a camera not in use may cause software instability.
- USB3 Vision development kits may cause software instability.